



VIDEO TUTORIAL

### Important!


This replacement procedure can be used for:

FORD FOCUS (DAW, DBW) 1.8 TDCi, FORD FOCUS Saloon (DFW) 1.8 TDCi,  
FORD FOCUS Turnier (DNW) 1.8 TDCi

---

The steps may slightly vary depending on the car design.

## REPLACEMENT: ANTI ROLL BAR LINKS – FORD FOCUS DAW. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Torque wrench
- Combination spanner #15
- Combination spanner #17
- Drive socket # 15
- Drive socket # 17
- Wheel impact socket #19
- Ratchet wrench
- Wheel chock

## Replacement: anti roll bar links – Ford Focus DAW. AUTODOC recommends:

- Replace the stabiliser links on Ford Focus DAW in pairs.
- The replacement procedure is identical for both stabiliser links on the same axle.
- Please note: all work on the car – Ford Focus DAW – should be done with the engine switched off.

## CARRY OUT REPLACEMENT IN THE FOLLOWING ORDER:

1

Secure the wheels with chocks.

2



Loosen the wheel mounting bolts. Use wheel impact socket #19.

3



Raise the front of the car and secure on supports.

4



Unscrew the wheel bolts.

### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while unscrewing the fastening bolts. Ford Focus DAW

5



Remove the wheel.

6



Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.



7



Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #17. Use a drive socket #17. Use a ratchet wrench.

8



Unscrew the fastener connecting the stabilizer link to the shock strut. Use a combination spanner #17. Use a drive socket #17. Use a ratchet wrench.

9



Remove the stabilizer rod.

10



Clean the mounting seats of the stabiliser link. Use a wire brush. Use WD-40 spray.

11



Install a new rod, tighten the fasteners. Use a combination spanner #15. Use a drive socket #15. Use a ratchet wrench.

12



Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a drive socket #15. Use a torque wrench. Tighten it to 50 Nm torque.



**13**


Tighten the fastener connecting the stabilizer link to the shock strut. Use a drive socket #15. Use a torque wrench. Tighten it to 50 Nm torque.

**14**



Treat all joints of the stabiliser link. Use copper grease.

15



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.

16



Clean the brake disk surface. Use a brake cleaner.

### AUTODOC recommends:

- Replacement: anti roll bar links – Ford Focus DAW. After applying the spray, wait a few minutes.

17



Install the wheel.

### AUTODOC recommends:

- Warning! To avoid injury, hold the wheel while screwing in the fastening bolts on the car. Ford Focus DAW

18



Screw in the wheel bolts. Use wheel impact socket #19.



19



Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #19. Use a torque wrench. Tighten it to 120 Nm torque.

20



Remove the jacks and chocks.

**DID YOU FIND THESE INSTRUCTIONS  
HELPFUL?**

**YES**

**NO**



**BECOME A MEMBER OF AUTODOC CLUB!**



# AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE

AUTODOC MOBILE APP: GREAT DEALS AND CONVENIENT SHOPPING



**AUTODOC APP**

**Download**

 **Google play**

 **App Store**

A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR



BUY SPARE PARTS FOR FORD



ANTI ROLL BAR LINKS: A WIDE SELECTION



CHOOSE CAR PARTS FOR FORD FOCUS DAW



ANTI ROLL BAR LINKS FOR FORD: BUY NOW



## ANTI ROLL BAR LINKS FOR FORD FOCUS DAW: THE BEST DEALS & OFFERS



### Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AutoDoc shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2018 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by Autodoc GmbH.